


# ClassicBond Installation Guide



# ClassicBond®

the original EPDM

## Field Installation Guide

# ClassicBond Installation Guide

## CONTENTS

<a href="#">General Information &amp; Precautions</a>	3
<a href="#">Tools, Equipment &amp; Roof Surface Preparation</a>	4
<b>Membrane Installation</b>	
<a href="#">Installation of ClassicBond roofing</a>	5 - 6
<a href="#">Mechanical Reinforcement / Securement</a>	7 - 8
<a href="#">Bonding Adhesive</a>	9
<a href="#">Pipes/Penetrations in membrane</a>	10
<a href="#">Skylights, Chimneys</a>	11
<a href="#">Perimeter Wall &amp; Vertical Terminations</a>	12
<a href="#">76mm Seam Tape</a>	13
<a href="#">150mm PS Cover Strip</a>	14
<a href="#">225mm PS Uncured Flashing</a>	15
<b>Pressure Sensitive Details</b>	
<a href="#">T-Joint Cover Patch</a>	16
<a href="#">Internal Corner Details</a>	17
<a href="#">External Corner Details</a>	18
<a href="#">Prefabricated Pipe Boot</a>	19
<a href="#">Pipe &amp; Penetration Flashing</a>	20
<b>Roof Outlets/Drains</b>	
<a href="#">Anti-Back-up 68mm Outlet</a>	21
<a href="#">ClassicBond Top Drain Outlet</a>	22
<a href="#">Angled Roof Drain Outlet</a>	23
<a href="#">On-site Fabricated Outlet</a>	24
<a href="#">EPDM to BUR Join</a>	25
<b>Perimeter Terminations</b>	
<a href="#">SureEdge PVC Gutter Trims</a>	26 - 27
<a href="#">SureEdge PVC Kerb Trims</a>	28 - 29
<b>Details</b>	
<a href="#">General</a>	30 - 54

# ClassicBond Installation Guide

## GENERAL INFORMATION

This Rooftop Guide has been designed to give the user a GENERAL overview of the application of a ClassicBond EPDM roof. This Guide is intended as broad reference aid and is not intended or meant to be all-inclusive.

## PRECAUTIONS

If the bonding adhesive is not allowed to properly dry, gas bubbles or blisters may form under the membrane sheet. These bubbles or blisters may subside over time.

Due to solvent flash off, condensation may form on freshly applied adhesive when the ambient temperature is near the dew point. If condensation develops, possible surface contamination may occur and the application of adhesive must be discontinued. Allow the surface to dry and when conditions allow apply a thin refresher coat at a coverage rate that is approximately half of the normal coverage rate when re-adhering a previously coated surface.

Extreme care must be exercised when working on ladders, roofs, or at elevations above ground. If used as an emergency repair to a roofing system, contact the roofing system manufacturer for compatibility and to ensure compliance with terms and limitations of the warranty.

Surface can be slippery when wet, damp, or frost covered.

Do not stretch the product during installation.

Do not expose product to temperatures in excess of 82° C (180°F).

This product is not intended for use where roof top traffic or activity is anticipated without a protective layer installed on its surface.

**THIS INFORMATION AS WELL AS INFORMATION CONTAINED IN THE SAFETY DATA SHEET AND ON PRODUCT PACKAGING MUST BE REVIEWED PRIOR TO STORAGE, HANDLING OR USE OF THESE PRODUCTS.**

# ClassicBond Installation Guide

## TOOLS & EQUIPMENT

- 50mm hand roller
- Hammer
- Hook blade knife/Scissors
- Pencils/Chalk Line
- 225mm medium pile roller on pole
- Chalk line
- Safety glasses
- Tape Measure
- 50-75mm brushes
- Stirrers for adhesive and primer
- Solvent resistant gloves
- Soft bristle broom
- Caulk gun
- Scrubbing pads for EPDM primer

## ROOF SURFACE PREPARATION

The ClassicBond fully-adhered system will adhere to wood, wood fibreboard, lightweight concrete & Glass Tissue Faced insulation suitable for fully adhered single ply systems. This product may NOT be applied to polystyrene insulation.

ClassicBond Water Based Acrylic Adhesive is intended for bonding to **timber surfaces only**. Other suitable surfaces **must** be bonded with ClassicBond Bonding Adhesive. Roofs over 100m<sup>2</sup> must also be fully installed with Bonding Adhesive.

Be sure the roof surface is clean, free of dust, dirt, rust, oil, grease, and loose material. The roof surface must be dry.

This product will not adhere to wet or damp surfaces. Trapped moisture may vaporize and negatively affect the performance of this product.

Good roofing practice dictates that ponding water be prevented. The roof surface should have a positive slope of at least 1 in 80 to prevent ponding water conditions. Before starting please consult the "Precautions" section at the beginning of this manual.

# ClassicBond Installation Guide

## INSTALLATION OF CLASSICBOND ROOFING

- Unroll the ClassicBond EPDM membrane over the substrate so that the sheet is in the desired position and is wrinkle free.
- The ClassicBond Water Based Acrylic Adhesive is intended for bonding to **timber surfaces only**. Other suitable surfaces must be bonded with ClassicBond Bonding Adhesive. Roofs over 100m<sup>2</sup> must also be installed with Bonding Adhesive.
- It is essential that ClassicBond EPDM membrane is allowed to relax prior to adhering. The time required for this will vary depending on weather conditions.
- Cut the membrane to length if required, and position the sheet to achieve an overhang off the roof of at least 75mm (3") for both the required length and width.
- RUSS (Reinforced Universal Secure Strip) should be installed wherever the membrane turns up through an angle change in excess of 9.5°, & to all perimeters where the roof exceeds 100m<sup>2</sup>. Consult Flex-R's Technical Department if in doubt.
- Fold the sheet onto itself so that one-half of the sheet is exposed; take care to avoid wrinkles.



# ClassicBond Installation Guide

- Open and thoroughly stir the [ClassicBond WBA Adhesive](#) or Bonding Adhesive. Using a medium pile paint roller apply the adhesive to the substrate, or if using Bonding adhesive, the rear of the membrane as well.
- The adhesive must be applied to 100% of the surface in an even coat without globs or puddles. The adhesive can alternatively applied in a thin coat to the membrane and substrate.
- Roll the sheet onto the coated substrate avoiding wrinkles by rolling the middle of the sheet first. Immediately after rolling the sheet into the adhesive, broom the membrane sheet to achieve maximum contact.



- DO NOT apply excessive pressure to cause the membrane to wrinkle.
- Repeat the application of ClassicBond WBA adhesive for the other half of the ClassicBond EPDM membrane.

NOTE: DO NOT APPLY WBA or BONDING ADHESIVE TO ANY SEAM AREAS.

# ClassicBond Installation Guide

## MECHANICAL REINFORCEMENT / SECUREMENT

In common with most single ply material EPDM will, overtime, try to shrink by up to 10% back to the centre. The base tie-in controls the membrane movement and stops the membrane pulling away where the membrane turns up through an angle change. The rest of the movement is accommodated by the ClassicBond membrane and its ability to elongate by over 300%.



ClassicBond PS RUSS (Reinforced Universal Secure Strip) is used to mechanically secure EPDM membranes to the substrate.

152mm RUSS has cured EPDM splice tape adhesive laminated along one edge. It can be installed horizontally or vertically in conjunction with Seam Fastening Plates below the EPDM membrane for additional membrane securement.

Seam Fastening Plates are used with RUSS to securely clamp the RUSS to the vertical or horizontal surface; these must be used in conjunction with the appropriate fasteners for the substrate.

ClassicBond should be mechanically secured wherever an inside angle of greater than  $9.5^\circ$  occurs. RUSS can be used to achieve this.

Securement must be provided at the perimeter of each roof level, roof section, expansion joint, curb flashing, skylight, interior wall, penthouse, etc., at any inside angle change where slope exceeds  $9.5^\circ$  and at other penetrations in accordance with ClassicBond details



# ClassicBond Installation Guide

All unreinforced EPDM's and most other single ply membranes produced, regardless of manufacturer, require mechanical securement to eliminate shrinkage and to install in accordance with manufacturers specifications.



1) Mechanically fasten the RUSS horizontally into the decking or into the upstand with the PS section being to the inside of the roof.



2) Apply ClassicBond Primer to the area on the underside of the EPDM membrane that will come into contact with the 75mm PS tape on the RUSS.



3) Once the primer is dry remove the protective strip from the PS tape on the RUSS. Lay the primed membrane into the PS tape with no wrinkles or air gaps and smooth in by hand then roll with hand roller.

# ClassicBond Installation Guide



4) Once bonded to the RUSS finish the upstand by using Bonding Adhesive to the remainder of the RUSS, upstand and membrane.

## BONDING ADHESIVE

[ClassicBond Bonding adhesive](#) is used on all vertical surfaces on the roof area, e.g. wall upstands, batten and sky light edges. This adhesive will work on porous and non-porous surfaces, providing they are clean and dry. The Bonding glue will enable tight angles to be formed quickly and easily to give great product versatility.



1) Apply the Bonding adhesive to the side of the RUSS or exposed decking. Also apply the Bonding adhesive to the relevant upstand termination or step down and to the back side of the ClassicBond membrane.



2) Once the adhesive has become touch dry with no wet puddles, mate the two surfaces together. Leaving no voids between the ClassicBond membrane and the receiving surface

# ClassicBond Installation Guide




3) Applying positive pressure to the membrane work the membrane up the upstand to the desired height. These areas should be rolled to achieve a strong bond between membrane and substrate.

## PIPES/PENETRATIONS IN MEMBRANE

When laying out the field sheets and a pipe or penetration is encountered, roll the folded membrane to the pipe. Be sure to maintain the proper alignment of the sheet with the roof edge, wall, and seams.

- Make a straight cut from the pipe to the nearest edge of the field sheet.
- Cut a hole to match the diameter of the pipe and roll the field sheet around the pipe.
- Check the final position of the sheet. Fold the membrane back and begin the bonding procedure.
- After the field sheet has been glued and broomed into place, apply a
- ClassicBond 150mm (6") wide Cured Cover Strip over the entire cut in the field sheet from the pipe to the outside edge of the sheet.


See the "Prefabricated Pipe Boot" section of this manual for further information on finishing this detail.



# ClassicBond Installation Guide

## SKYLIGHTS & CHIMNEYS

- Prior to applying the adhesive, and while maintaining proper sheet alignment with walls, perimeter edges and other protrusions, unroll the membrane up to the base of the unit.



- Measure the width and depth of the unit and transfer the corresponding dimensions onto the folded membrane. Draw an “X” inside the box. Cut the “X” mark and from one corner cut a straight line to the nearest edge of the membrane.
- Roll the membrane around the unit, leaving a triangle of membrane turning up each one of the four (4) sides.
- After all cuts are made and the membrane has been correctly positioned, fold the membrane back and begin bonding procedures.
- After the field area is complete, bond the triangles up the sides of the unit (chimney, skylight, etc.). Take care to bond the membrane into the angle change so that the membrane is completely adhered.
- After the field sheet has been glued and broomed into place, apply a ClassicBond 150mm (6”) Cover strip over the entire cut in the field sheet from the curb to the end of the sheet.

## PERIMETER WALLS

The membrane on the wall should be a continuation of the deck membrane, base tie-ins are used at the perimeter of the roof.


# ClassicBond Installation Guide

The membrane should extend up the wall as far as possible to prevent the possibility of moisture infiltration behind the membrane. The membrane must extend up the wall a minimum of 150mm.

## VERTICAL TERMINATION


### Wall Trim

- After the desired flashing height is attained and the membrane has been adhered.
- Insert the trim into the previously cut chase and mechanically fix into place using RB fasteners at a max spacing of 500mm..
- Apply a bead of Lap Sealant along the top of the trim and wall.



### Coping Stone

- Lay ClassicBond EPDM 2/3rds across the wall, using Bonding adhesive and apply a bead of water cut off mastic under the outside edge of membrane and compress.
- Apply an even bed of mortar from the membrane and onto the out brick wall
- Lay suitable coping stones ensuring they have sufficient over hang and drip channels.



# ClassicBond Installation Guide

## SEAMS

### 75MM PS TAPE

The membrane should be positioned so that the width of the seam is 75mm (3"). Mark a line 5mm (1/4") from the leading seam edge.



1) Fold the top sheet back to expose the seam area. Using a scrubbing pad apply the ClassicBond Primer to the seam area. Apply the primer past the seam edge to the line. ClassicBond Primer must be dry before application of PS tapes.

NOTE: If the EPDM membrane is contaminated with dirt, etc., clean the seam area.



2) Using moderate pressure set the Seam Tape into place to keep air from being trapped under the tape and unroll the 75mm wide tape along the length of the seam, aligning the Seam Tape (not the clear backing) along the chalk line. Care must be taken not to get any bubbles or wrinkles in the tape.



3) Lay the top membrane onto the Seam Tape. Pull away the poly backing from the tape at a 45° degree angle to the seam. While removing the poly backing, draw your hand across the seam, from the back to the leading edge. Roll the seam at right angles to the seam direction, not along it.

# ClassicBond Installation Guide

## 150MM PS COVER STRIP

When butt jointing of ClassicBond membrane or seaming to a metal drip or similar a 150mm cover strip is used.



1) Ensure there is no gap between the membrane when butt jointing. The 150mm tape should be centrally located over the joint.



2) Apply ClassicBond Primer to the area to be seamed. Apply primer 80-100mm either side of the join in the EPDM sheets.



3) Once the ClassicBond Primer has dried, peel back 150mm of the poly backing and press the PS tape into the primed area. Once the tape is held in position, peel back the poly backing and smooth the tape into the primed area. Progress along the seam.



4) Once the entire length of tape is applied to the seam, roll across the 150mm tape with hand roller. Where 150mm tapes intersect other tapes, 225mm uncured tape cover patches must be applied.

# ClassicBond Installation Guide

## 225MM PS UNCURED FLASHING TAPE

This tape is used for any detail work necessary on the roof. It has the ability to mould to almost any shape and will adhere to most surfaces, provided the surface is clean, dry, and correctly primed with the HP250 primer.

- To seal pipes, penetrations, corners and other details.
- Adaptable to irregular shapes and surfaces.
- Self-curing membrane.

**IF 225MM PS FLASHING MAY BE SUBJECTED TO SUBMERSION OR HIGH FLOW OF WATER, ALL EDGES SHOULD BE PROTECTED WITH CARLISLE LAP SEALANT. LAP SEALANT HELPS TO KEEP WATER FROM INFILTRATING BETWEEN THE FLASHING PLY AND THE TAPE PLY BEFORE THE FLASHING HAS FULLY CURED ON THE ROOF.**

Typical details are shown on the following pages.


# ClassicBond Installation Guide

## T-JOINTS

A T-Joint is formed when two sheets of membrane form a seam that travels under, or over, a third section. The centre of the “T” is where the three sheets intersect.


- Use ClassicBond Uncured Flashing to form T-Joint patches. T-Joint patches should be at least 150mm (6”) x 150mm (6”).
- Apply primer to membrane surface before applying T-Joint patches.

NOTE: All T-Joint Patches should be thoroughly rolled with a steel or silicone hand roller.



# ClassicBond Installation Guide

## INTERNAL CORNER



1) The fold should be cut back to leave a 75mm wide flap. Apply ClassicBond EPDM Primer to the front & back of the flap and to the membrane on the wall. ClassicBond Primer must be allowed to dry before application of PS tape.



2) Cut an appropriate size piece of 225mm uncured flashing (min. 50mm wider than the flap of membrane), press the flap back to the upstand and install the uncured flashing tape.



3) Roll the taped area with hand roller once installed.

# ClassicBond Installation Guide

## EXTERNAL CORNERS

1) Cut the ClassicBond EPDM membrane at 45° angle to allow the membrane to run around the corner and create both upstands. Bond in place with ClassicBond Bonding Adhesive. Cut a section of 225mm Uncured PS tape to a min. 75mm onto deck and 50mm past angled cut in membrane.



2) Apply ClassicBond Primer to the marked area to be flashed and allow to dry. The area must be clean and dry before application of primer, apply primer to membrane and to upstand substrate. ClassicBond Primer must be allowed to dry before application of tapes.



3) Start installing the tape from the top point. Work the tape down upstands first and into the bottom angle change.



4) Work the tape onto the deck around the corner and smooth out and roll the entire flashing with hand roller.

# ClassicBond Installation Guide

## PRE-FABRICATED PIPE SEAL




1) Cut the ClassicBond PS Pipe Seal above the raised "rib" one size smaller than the pipe diameter. DO NOT CUT THROUGH THE RIB. Pull pipe seal over pipe until base flange is in contact with the ClassicBond EPDM membrane.



2) Once in position clamp the seal to the pipe with the supplied metal clamp and mark around the base of the seal to give a line to prime up to. Pull pipe seal upwards on pipe to expose the membrane and apply ClassicBond EPDM Primer to the EPDM deck membrane



3) Pull pipe seal back down over pipe and into position. Remove poly backing from the tape and with hand pressure press tape onto primed area. Roll splice area with a hand roller




Apply ClassicBond uncured T-Joint Patches where pipe seal intersects a field splice.

NOTE: Temperature of the pipe must not exceed 82° C (180° F)

# ClassicBond Installation Guide


## PIPE AND PENETRATION FLASHINGS

To fabricate a pipe boot or flashing for other penetrations follow the procedures on the following pages using ClassicBond Uncured Flashing.



ClassicBond PS Uncured  
225mm Tape

ClassicBond EPDM  
Membrane



# ClassicBond Installation Guide

## INTERNAL DRAIN

There are two basic methods for sealing to an internal drain. ClassicBond Pre-made outlets of various types can be used for standard outlets or an on-site method may be used for non-standard outlets.

## ANTI-BACKUP DRAIN FOR 68MM OUTLET

These are 68mm roof outlets designed to be inserted into the existing 68mm diameter down pipe. The outlet is fitted with an anti-backup seal to achieve a watertight joint. The outlet is attached to the membrane using 225mm PS uncured flashing tape. A Leaf grate for this outlet is also available.



1) Cut the outlet flange back to leave a min. 50mm head and cut the membrane back to meet the perimeter of the outlet head. Secure the outlet into the decking and apply ClassicBond Primer to the head of the outlet and to the EPDM membrane.



2) Apply the Uncured PS tape to the primed area. Once fitted cut a small section from the centre of the tape out to expose the outlet opening and press the remaining tape down into the outlet. Roll the entire flashing with hand roller.



3) Finally install the leaf grate to complete the 68mm flat roof outlet.

# ClassicBond Installation Guide

## CLASSICBOND TOP DRAIN

These are designed for 110mm flat roof outlets to allow high water flow on larger roofs.



1) Fit the outlet into the roof before installing the membrane; ensure the outlet has the yellow protective cap installed. Install the ClassicBond EPDM membrane to the roof and over the outlet, place cutting guide over the pin and cut round the circular plate.



2) Remove the circular section of membrane and the yellow protective cap from the outlet.



3) Insert a bead of ClassicBond Water Cut Off mastic between the underside of the membrane and the top flange on the outlet. Screw in the clamping ring till it's completely tightened. Use the two tightening lugs to apply leverage to the ring.



4) Install the leaf grate into the three locating tabs.

# ClassicBond Installation Guide

## ANGLED ROOF DRAIN

For roofs designed with horizontal drains to go through walls and pitched roofs. The ClassicBond Angled Roof Drain is fitted to the deck and sealed to the membrane using 225mm PS Uncured flashing tape.



1) Install outlet into parapet wall before installing EPDM membrane. Install the ClassicBond EPDM membrane over the outlet with ClassicBond Bonding Adhesive. Cut the EPDM membrane away from outlet opening by 50mm. Apply ClassicBond Primer to the membrane, outlet face and into the outlet pipe.



2) Install Uncured PS tape to the outlet. This should be large enough to join onto the membrane by a minimum of 50mm. Cut a small square out of the middle of the tape and mould the tape into the outlet pipe by 25mm. Cut a second section of Uncured PS tape 100mm wide. This will be inserted into the outlet pipe to reinforce and lengthen the tape that was turned into the pipe by 25mm. Apply ClassicBond Primer to outlet pipe and to already installed tape before application.




3) Once the second section of tape is installed, complete by inserting the leaf grate into the outlet.

# ClassicBond Installation Guide

## FOR NON-STANDARD OUTLET DESIGN

This method uses just the 225mm PS uncured flashing tape to seal the membrane to the outlet pipe.





# ClassicBond Installation Guide

## EPDM TO BUR TERMINATION

There are two alternate methods to be used when the new ClassicBond roof joins directly onto a neighbouring flat roof.

The diagram below shows a cold termination and simple guidelines to follow in the planning stage of the roof.



# ClassicBond Installation Guide

## EDGE TERMINATIONS

### SUREEDGE PVC PERIMETER TRIMS


Offering a fast simple, good looking finish to the flat roof system. See more at [www.sureedge.co.uk](http://www.sureedge.co.uk).

### GUTTER SYSTEM

This is available in two options, standard and built in batten back plate. The standard requires a timber batten to be installed first then the back plate fixed to it. The “Built in Batten” doesn’t require the extra timber batten.



- Fix the 25mm x 40mm back plate to the fascia at the edge of the roof.
- Allow minimum 50mm ClassicBond membrane to go over the back plate
- Position the front plate with foam seal to clamp the membrane between the 2 sections and fully fix into place with supplied fixings.
  - Between lengths allow 2.5mm expansion joint for each trim




Note: In areas of high wind, exposed areas and high buildings additional fixings between predrilled holes is recommended.

# ClassicBond Installation Guide



## Gutter Trim Joiner



Install joint covers by hooking the clip under the bottom of the front plate and clipping the top over.



## Gutter Corners

### External


- Apply the adhesive to one side of the corner
- Push down into position and hold till adhesive is set.



### Internal

- Apply the adhesive to one side of the corner
- Push down into position and hold till adhesive is set.

# ClassicBond Installation Guide



## Sure Edge Check Kerb System

Used to create upstand and edge trim in one component.

- Lay membrane and allow minimum 50mm overhang.
- Ensure membrane is clean, position edge trim and firmly push down to compress foam seal by min. 30%.
- Fix trim into place using supplied fixings.
- Between lengths allow 2.5mm expansion joint for each trim.

Note: If a secure fixing cannot be achieved a timber fixer should be fitted to the vertical edge of the roof.



In areas of high wind, exposed areas and high buildings additional fixings between predrilled holes is recommended.



## Kerb Joiner



Install joint covers by hooking the clip under the bottom of the clip under the front plate and clipping the top over.

# ClassicBond Installation Guide



## Internal Corner

- Mitre the trims so they fit together with foam seal compressing between the two trim ends
- Apply adhesive to one side of the corner
- Fit over trims and hold in place till set.






## External Corner / Stop End

This universal corners is designed for both external check corners and stop end for gutter.

## External Corner

- Mitre the trims so they fit together with foam seal compressing between the two trim ends
- Remove the two blanking plates
- Apply adhesive to one side of the corner
- Fit over trims and hold in place till set.



## Stop End


- Remove one blanking plate for the relevant side
- Apply adhesive to one side of the corner
- Fit over trims and hold in place till set.

# ClassicBond Installation Guide

## DETAILS



# ClassicBond Installation Guide



 The original EPDM www.classicbond.co.uk		<b>Title</b> COPING STONE DETAIL	
<b>Product</b> CB-W-3		<b>Drawn</b> <input checked="" type="checkbox"/> <b>Checked</b> <input checked="" type="checkbox"/> <b>Approved</b> <input checked="" type="checkbox"/> <b>Scale</b> MFO DW DW 1:40A4	
<b>Rev</b> <b>Date</b> <b>Comments</b>		<b>Status</b> <b>PRODUCTION</b>	
A 03.02.14 PRODUCTION Issue		<b>Date</b> 03.02.14	
<b>Drawing No:</b> CB/W/3		<b>Rev:</b> B	

# ClassicBond Installation Guide

1. ClassicBond EPDM Membrane  
 2. ClassicBond Decking Adhesive (See Notes)  
 3. ClassicBond Thermal Insulation  
 4. Suitable thermal insulation, thickness determined by U-value  
 5. Vapor Control Layer (VCL)  
 6. Structural decking  
 7. ClassicBond termination Bar  
 8. ClassicBond Universal Secure Strip  
 9. ClassicBond Water Call Off Mastic  
 10. ClassicBond Water Call Off Mastic  
 11. Reinforced Universal Secure Strip (RUSS)  
 12. Suitable Fastener with 50mm Stem Profile

150mm Min. Upstand

Front View of Termination Bar

Min. 6.00 mm  
Max. 13 mm

Diagram 2

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12


Notes:  
 1. Membrane shall be incorporated to serve as an upstand in appropriate, non-slippery, typical building conditions and (outside the context and application of ClassicBond products only).  
 2. Make the membrane protrude by this detail 1.50m or more in accordance with specific project conditions, detailing and requirements.  
 3. The membrane shall be applied to the substrate in accordance with the manufacturer's instructions.  
 4. The membrane shall be applied to the substrate in accordance with the manufacturer's instructions.  
 5. If structural concrete is used, the concrete shall be covered with a 25mm nominal EPS/VAI/PSI.  
 6. Also include a detail for a VCL as shown in Figure 12.2.  
 7. The membrane shall be applied to the substrate in accordance with the manufacturer's instructions.  
 8. The membrane shall be applied to the substrate in accordance with the manufacturer's instructions.  
 9. The membrane shall be applied to the substrate in accordance with the manufacturer's instructions.  
 10. The membrane shall be applied to the substrate in accordance with the manufacturer's instructions.  
 11. The membrane shall be applied to the substrate in accordance with the manufacturer's instructions.  
 12. The membrane shall be applied to the substrate in accordance with the manufacturer's instructions.

Title		TERMINATION BAR DETAIL	
Product		CB-W-2	
Rev	Date	PRODUCTION Issue	Comments
A	03.02.14		
Drawing No:		CB-W/2	
Drawn	Checked	Approved	Scale
MFO	DW	DW	1:4@A4
Status	PRODUCTION		Date
			03.02.14
Rev:		B	

ClassicBond®  
 the original EPDM  
 www.classicbond.co.uk




# ClassicBond Installation Guide




 the original EPDM www.classicbond.co.uk		<b>Title</b> FLAT ROOF TO PITCH ROOF LEAD TERMINATION (MANSARD)	
<b>Product</b> CB-1-3		<b>Rev</b> A	
<b>Date</b> 03.02.14		<b>Comments</b> PRODUCTION ISSUE	
<b>Drawing No.</b> CB/T/3		<b>Scale</b> 1:4@A4	
<b>Checked</b> MFO		<b>Approved</b> DW	
<b>Date</b> 03.02.14		<b>Date</b> 03.02.14	
<b>PRODUCTION</b>			
<b>Rev</b> A		<b>Rev</b> A	

# ClassicBond Installation Guide





		<b>Title</b> FLAT ROOF TO PITCH ROOF TERMINATION (MANSARD)	
<b>Product</b> CB-1-2		<b>Revision</b> A 03.02.14	
<b>PRODUCTION Issue</b> Comments		<b>Drawing No:</b> CB/1/2	
<b>Drawn</b> MFO	<b>Checked</b> DW	<b>Approved</b> DW	<b>Scale</b> 1:4@A4
<b>PRODUCTION</b>		<b>Date</b> 03.02.14	
<b>Rev:</b> A			

# ClassicBond Installation Guide



# ClassicBond Installation Guide

## Alternative Securement Diagram




External Corner formed using ClassicBond 225mm PS Uncurved Flashing Tape, conforming to standard design principals. See Classic Bond Installation Guide for further details

- Notes**
- The detail was prepared to serve as a guideline representing typical detailing conditions and illustrate the correct application of ClassicBond products only. It may be necessary to modify this detail in whole or part in accordance with specific project conditions, design or requirements.
  - All Pressure Sensitive Plates are to be secured using HP Fasteners at a maximum of 300mm centres.
  - Lap Sealant should be applied to 225mm PS Taps at high water flow areas.

**Key:**


- ClassicBond EPDM Membrane
- ClassicBond Decking Adhesive (See Notes)
- Suitable thermal insulation, thickness determined by U-value
- Vapour Control Layer (VCL)
- Skylight (by others) installed onto 11mm thick concrete
- 150mm PS Cover Strip, maintaining minimum 75mm coverage to field membrane and upstand flashing
- HP Fastener with 50mm Seam Plate



 the original EPDM www.classicbond.co.uk		<b>Title</b> SKYLIGHT KERB DETAIL, DECK MECHANICAL FASTENER		<b>Product</b> CB	
<b>Drawn</b>	<b>Checked</b>	<b>Approved</b>	<b>Scale</b>	<b>Date</b>	<b>Rec</b>
CUB			1:4@A4	31.01.17	
<b>Status</b>					
<b>Rev</b>	<b>Date</b>	<b>Comments</b>			
<b>Drawing No</b>			<b>Rev</b>		
CB / Skylight Kerb			152mm PS PS Tape		


# ClassicBond Installation Guide

## Alternative Securement Diagram



- Notes**
- The detail was prepared to serve as a guideline representing typical detailing conditions and illustrate the correct application of ClassicBond products only. It may be necessary to modify this detail in whole or part in accordance with specific project conditions, design or requirements.
  - All Pressure Sensitive Plates are to be secured using HP fasteners at a maximum of 300mm centres.
  - Lap Sealant should be applied to 228mm PS Taps at high water flow areas.

- Key:**
- ClassicBond EPDM Membrane
  - ClassicBond Dacking Adhesive (See Notes)
  - Suitable thermal insulation, thickness determined by U-value
  - Vapour Control Layer (VCL)
  - Skylight (by others) installed onto 11mm 78mm PS SecuTAPe
  - 78mm PS SecuTAPe
  - HP Fastener with 50mm Seam Plate




External Corner formed using ClassicBond 228mm PS Unleaded Flashing Tape, conforming to standard design principle. See Classic Bond Installation Guide for further detail.

 the original EPDM www.classicbond.co.uk		This <b>SKYLIGHT KERB DETAIL, DECK</b> MECHANICAL FASTENER Product CB		Drawn CUB Status	Checked Approved Scale 1:4@A4	Date 31.01.17
Rev	Date	Comments		Rev	Date	Rec

# ClassicBond Installation Guide



NOTE:  
 1. ClassicBond EPDM Membrane  
 2. ClassicBond Bonding Adhesive (See Notes)  
 3. ClassicBond Bonding Adhesive  
 4. Suitable thermal insulation, thickness determined by U-value  
 5. Vapor barrier (VBS)  
 6. Structural decking  
 7. ClassicBond Pressure Sensitive EPDM Tape  
 8. Skylight (By others)  
 9. Reinforced Universal Secure Strip (RUSS)  
 10. Suitable Fastener with Storm Seam Plate



 the original EPDM www.classicbond.co.uk		Title <b>SKYLIGHT DETAIL (PS TAPE)</b>		Product <b>CB-SK-1</b>	
A 03.02.14 New Date		PRODUCTION Issue Comments		Drawing No. <b>CB/SK/1</b>	
MFO DW DW Scale <b>1:4@A4</b>		Approved DW DW Date <b>03.02.14</b>		Rec B	
PRODUCTION					

# ClassicBond Installation Guide

1. ClassicBond EPDM Membrane
2. ClassicBond Decking Adhesive (See Notes)
3. ClassicBond Isoborn PS Cover Strip
4. ClassicBond PS Cover Strip (Thickness determined by U-value)
5. Vapour Control Layer (VCL)
6. Structural Decking




**NOTE:**  
 This data was produced by using a standard representative typical condition for each product. The actual performance of ClassicBond products may vary depending on the specific conditions of use. For more information, please contact your local ClassicBond representative.  
 1. Acrylic Decking Adhesive is for new substrates only, all other suitable surfaces use ClassicBond Bonding Adhesive.  
 2. Acrylic Decking Adhesive is for new substrates only, all other suitable surfaces use ClassicBond Bonding Adhesive.  
 3. ClassicBond PS Cover Strip thickness is determined by U-value.  
 4. A field splice installation refers to a section of 22mm bonded EPDM Membrane flashing or cover patch.

 the original EPDM www.classicbond.co.uk		<b>Title</b> END LAP SPLICE / PS COVER STRIP		<b>Product</b> CB-S-2	
<b>Rev</b> A		<b>Date</b> 03.02.14		<b>Comments</b> PRODUCTION issue	
<b>Drawing No:</b> CB/S/2		<b>Scale</b> 1:4@A4		<b>Date</b> 03.02.14	
<b>Drawn</b> MFO		<b>Checked</b> DW		<b>Approved</b> DW	
<b>Status</b> PRODUCTION		<b>Scale</b> 1:4@A4		<b>Date</b> 03.02.14	
<b>Rev</b> A		<b>Scale</b> 1:4@A4		<b>Date</b> 03.02.14	

# ClassicBond Installation Guide

1. ClassicBond EPDM Membrane
2. ClassicBond Decking Adhesive (See Notes)
3. ClassicBond 75mm Splice Tape
4. Suitable thermal insulation, thickness determined by U-value
5. Vapour Control Layer (VCL)
6. Structural Decking



**Notes:**  
 This detail may be required to meet a higher or varying type of building code and must be checked against the local code book of ClassicBond products only.  
 1. The membrane must be applied to a clean, dry, and smooth substrate.  
 2. Apply the adhesive to the substrate only, all other materials must be ClassicBond bonding products.  
 3. The membrane must be applied to a clean, dry, and smooth substrate.  
 4. At 1000 g/m<sup>2</sup> minimum, apply a minimum of 2.0mm Unvered Elastomer Sheeting as cover advice - refer to sheet CBS-2

 the original EPDM www.classicbond.co.uk		<b>Title</b> MEMBRANE SPLICE WITH 75mm SEAM TAPE		<b>Product</b> CB-S-1	
<b>Rev</b> A		<b>Date</b> 03.02.14		<b>Comments</b> PRODUCTION Issue	
<b>Drawing No:</b> CB/S/1		<b>Scale</b> 1:4@A4		<b>Date</b> 03.02.14	
<b>Drawn:</b> MFO		<b>Checked:</b> DW		<b>Approved:</b> DW	
<b>Status</b> PRODUCTION		<b>Scale</b> 1:4@A4		<b>Date</b> 03.02.14	
<b>Rev</b> A		<b>Comments</b> PRODUCTION Issue		<b>Rev</b> A	

# ClassicBond Installation Guide

See Note 2


1. ClassicBond EPDM Membrane
2. ClassicBond Decking Adhesive (See Note 5)
3. ClassicBond Pressure Sensitive Pipe Boot
4. Vapor Control Layer (VCL) (Thickness determined by U-value)
5. Vapor Control Layer (VCL)
6. Structural Decking
7. Stainless steel clamping ring

**Notes:**

1. Membrane must be prepared to meet the installation requirements listed in the conditions and limitations of ClassicBond products only.
2. Membrane must be applied to the substrate in a clean, dry, and well-ventilated area. The substrate must be prepared in accordance with the specific product code, design, or requirements.
3. Vapor Control Layer (VCL) thickness must be determined in accordance with the specific product code, design, or requirements.
4. The seal is suitable for pipes 20mm - 150mm in diameter.

 the original EPDM www.classicbond.co.uk		Title <b>PRE-FABRICATED PIPE SEAL</b>	
Product <b>CB-P-2</b>		Drawing No. <b>CB/P/2</b>	
Rev <b>A</b>	Date <b>03.02.14</b>	Production Issue <b>PRODUCTION</b>	Rev <b>A</b>
Status <b>PRODUCTION</b>	Scale <b>1:4@A4</b>	Date <b>03.02.14</b>	
Down <b>MFO</b>	Checked <b>DW</b>	Approved <b>DW</b>	Date <b>1:4@A4</b>

# ClassicBond Installation Guide



- Notes
1. This data was prepared to serve as a guideline, dependent on local codes and standards and it utilizes the current application of ClassicBond products only.
  2. ClassicBond Decking Adhesive is for interior substrates only, all other suitable alternatives ClassicBond Structural Slabbing Adhesive.
  3. Material indicated using "dependent" 255mm Uncoated Blatexform Flashing 1.403.

 The original EPDM www.classicbond.com		Title <b>FIELD FABRICATED PIPE SEAL</b>		Product <b>CB-P-1</b>	
Rev	Date	Issue	Comments	Drawn	Checked
A	03.02.14	PRODUCTION		MFO	DW
Status <b>PRODUCTION</b>				Scale	Date
Drawing No. <b>CB/P/1</b>				1:4@A4	03.02.14
				Rev	Rev
				A	A

# ClassicBond Installation Guide

Notes:

1. This detail was prepared to meet a customer requirement for ceiling conditions and application of ClassicBond products only. It may be necessary to modify this detail in accordance with specific project conditions, design requirements, and local building codes.
2. Refer to ClassicBond website for further information on ClassicBond products and services.


Legend:

1. ClassicBond EPDM Membrane
2. ClassicBond Decking Adhesive
3. 18mm timber former (min. 75mm depth)
4. Insulation (min. 18mm thickness determined by U-value)
5. Vapor Barrier (VBS)
6. Structural Decking

Title		EDGE TRIM	
Product		CB-GT-3	
Rev	Date	Comments	Issue
A	03.02.14	PRODUCTION	Issue
Drawing No:		CB/GT/3	
Drawn	Checked	Approved	Scale
MFO	DW	DW	1:4@A4
Status		PRODUCTION	
Date		03.02.14	
Rev			A

ClassicBond®  
the original EPDM  
www.classicbond.com

# ClassicBond Installation Guide



# ClassicBond Installation Guide

**Note:**  
 1. The metal must be prepared to receive the adhesive representative of the ceiling, ceiling cover and the sealant used for correct installation of ClassicBond products only.  
 2. The maximum depth of the metal must be 30mm in order to accommodate the adhesive.  
 3. The maximum depth of the metal must be 30mm in order to accommodate the adhesive.  
 4. The maximum depth of the metal must be 30mm in order to accommodate the adhesive.  
 5. The maximum depth of the metal must be 30mm in order to accommodate the adhesive.  
 6. The maximum depth of the metal must be 30mm in order to accommodate the adhesive.  
 7. The maximum depth of the metal must be 30mm in order to accommodate the adhesive.  
 8. The maximum depth of the metal must be 30mm in order to accommodate the adhesive.

1. ClassicBond EPDM Membrane
2. ClassicBond Bonding Adhesive (See Notes)
3. ClassicBond Bonding Adhesive (See Notes)
4. Outside thermal insulation thickness determined by U-value
5. Structural insulation (SIL)
6. Structural decking
7. Prefabricated metal edge trim @ 300mm max centres (See Notes)
8. 150mm PS Cover Flashing

**Title**  
METAL EDGE TRIM

**Product**  
CB-GT-1

Rev	Date	Comments
A	03.02.14	PRODUCTION ISSUE

**Drawing No.**  
CB/GT/1

Drawn	Checked	Approved	Scale	Date
MFO	DW	DW	1:4@A4	03.02.14

**STATUS**  
PRODUCTION

**Rev**  
A

**ClassicBond**  
the original EPDM  
www.classicbond.co.uk

# ClassicBond Installation Guide

1. ClassicBond EPDM Membrane  
 2. ClassicBond Bonding Adhesive  
 3. Outside thermal insulation, thickness determined by U-value  
 4. Vapor barrier layer (VBL)  
 5. Structural slabs  
 6. Sure Edge PVC Check Keel (See Note)  
 7. Sure Edge PVC Secure Strip (RUSS)  
 8. Reinforced Universal Seam Strip (RUSS)  
 9. Suitable Fastener with 50mm Seam Plate

NOTE:  
 1. This detail was prepared to serve as a guideline representing typical climatic conditions and shall state the correct application of ClassicBond products only.  
 2. The design of the roof structure shall be in accordance with the relevant building code.  
 3. Specifications for materials may need to be subject to different weather dependent or weather sensitive conditions.  
 4. The installation shall be in accordance with the relevant building code.  
 5. Check the relevant building code for details.

 The original EPDM www.classicbond.co.uk		This <b>EDGE TRIM</b> (SURE EDGE PVC KERB)		Product <b>CB-ET-3</b>	
A 28.01.14 Date		PRODUCTION Issue		Drawing No: CB/ET/3	
New		Comments		Rec: B	
Drawn MFO	Checked DW	Approved DW	Scale 1:4@A4	Date 29.01.14	
PRODUCTION					

# ClassicBond Installation Guide



www.classicbond.co.uk

**Title**  
EDGE TRIM + 150mm PS

**Product**  
OB-ET-2

**Drawn** / **Checked** / **Approved** / **Scale** / **Date**  
MFO / DW / DW / 1:40A4 / 29.01.14

**Status** / **PRODUCTION**

**Rev** / **Date** / **Comments**

A	28.01.14	PRODUCTION Issue

**Drawing No:** OB/ET/2      **Rev:** B

**Notes:**

1. Substrate prepared to comply with applicable requirements listed under the correct application of ClassicBond products, apply primer, see necessary to modify the detail in order of repair or accordance with specific project conditions, design or installation.
2. Reinforced Universal Secure Strip (RUSS)
3. ClassicBond Bonding Adhesive
4. Suitable thermal insulation, thickness determined by U-value
5. Vapour Control Layer (VCL)
6. Structural decking
7. Suitable cavity bridge
8. Suitable metal edge trim
9. 150mm ClassicBond PS Cover Strip
10. Prefabricated metal edge trim
11. Reinforced Universal Secure Strip (RUSS)
12. Suitable Fastener with 50mm Stem Plate





Diagram 2


# ClassicBond Installation Guide







# ClassicBond Installation Guide



# ClassicBond Installation Guide

**Alternative position of RUSS over timber nailer. PS Tape faces main roof area.**

**Note 2**  
Pressure Sensitive angle change over pitch

**Notes:**

1. The seal and product to serve as a positive waterproofing for all detailing conditions and all other correct application of ClassicBond products only.
2. The gutter channel should be installed on a level surface or on a surface that is sloped to the gutter.
3. If forming with square timber nailer, apply the gutter channel to the roof slope through a rigid Pressure Sensitive Cover Patch using ZSMB® or covered EPDM 1400.
4. The membrane should overlap in a single lap.
5. The membrane should overlap in a single lap between the RS's. The overlap should be a minimum of 100mm.

**Legend:**

1. ClassicBond EPDM Membrane
2. Reinforced Universal Secure Strip (RUSS)
3. Suitable Fastener with Glimm Seam Plates
4. ClassicBond Decking Adhesive
5. ClassicBond Bonding Adhesive
6. Suitable Thermal Insulation, thickness determined by U-value
7. Suitable Overlaid (VCL)
8. Structural Decking
9. Treated timber by others

**Table 1: Product Information**

Title	BOX GUTTER
Product	CB-BG-1

**Table 2: Revision History**

Rev	Date	Comments
A	03.02.14	PRODUCTION ISSUE

**Table 3: Drawing Status**

Drawn	Checked	Approved	Scale	Date
MFO	DW	DW	1:4@A4	03.02.14

**Table 4: Production Information**

Status	PRODUCTION
Drawing No.	CB/BG/1
Rev.	B

**ClassicBond**  
the original EPDM

# ClassicBond Installation Guide

## Disclaimer

All the information in this product sheet is based on practical experience and is published in good faith. However, because we have no control over the manner or conditions in which our products are used, or over work undertaken or end product manufactured by the purchaser, we cannot accept liability for results.

Responsibility for ascertaining the suitability of products for their purposes rests with the purchaser. All conditions, representations, statements, warranties or guarantees whatsoever, whether express, implied or statutory, in respect of any goods manufactured, sold or supplied by us are hereby expressly excluded and we accept no liability in respect of any claim for damage or consequential loss caused to any property arising directly or indirectly out of the use of our products or goods.

Flex-R, Sandwood House, Hillbottom Road, Sands Industrial Estate, High Wycombe, Bucks, HP12 4HJ

Tel: 01494 448792, [eng@classicbond.co.uk](mailto:eng@classicbond.co.uk), [www.classicbond.co.uk](http://www.classicbond.co.uk)